

## Voice Memo

You can use the Voice Memo feature to:

- Record up to four voice memos
- Play the recorded voice memos
- Delete one or all voice memos

### Voice Memo Record

*Menu 4-1*

This option allows you to record a memo. The screen displays the:

- Memo location
- Date and time when the memo is recorded
- Recording time counter

The maximum recording time is about 35 seconds.

If you want to record for longer, press the **Continue** soft key. **Split** appears instead of **Continue**. You can continue recording and the rest of the memo is stored in the next memo location.

To stop recording, press the **Stop** soft key.

**Note:** If all memo locations are full, you must delete an old memo before recording a new one.

**Voice Memo**

**Voice Memo Replay** *Menu 4-2*

This option allows you to play back all memos recorded, starting with the most recent memo. The screen displays the:

- Memo location
- Date and time when the memo was recorded.

To...	Then press the...
Skip to the next memo	<b>Skip</b> soft key.
Stop the playback	<b>Stop</b> soft key.

**Voice Memo Delete One** *Menu 4-3*

This option allows you to delete a specific memo. All memos recorded are played back, starting with the most recent one.

To...	Then press the...
Delete the memo being played	<b>Delete</b> soft key.
Skip to the next memo	<b>Next</b> soft key.

**Voice Memo Delete All** *Menu 4-4*

This option allows you to delete all memos. Press the **OK** soft key to confirm.



# Sound Settings

You can use the Sound Settings feature to customise various settings, such as the:

- Ringing tone, volume and type
- Sounds made when you press a key, make an error or receive a message

**Ring Tone** *Menu 5-1*

This option allows you to select the required ringing tone. You can choose between eleven different tones. Each time you select a tone, it is played for a few seconds.

**Ring Volume** *Menu 5-2*

This option allows you to adjust the ringing volume to one of five levels. Use the **Up** and **Down** keys on the left side of the phone. The greater the number of bars, the greater the volume.

**Alert Type** *Menu 5-3*

This option allows you to indicate how you are to be informed of any incoming calls. The following options are available.

**Light only:** only the backlight is switched on; the phone neither rings nor vibrates.

**Sound Settings**

**Melody:** the phone rings using the ringing tone selected via menu option 5-1.

**Vibration:** the phone vibrates but does not ring.

**Vibra+Melody:** the phone both rings and vibrates.

If you hold down the „ key on the left side of the phone when the phone is in the idle mode, the alert type (except for vibration) set via this option quickly switches to the vibration mode. If the vibration mode is already set, it switches to the melody mode. To select other alert types, set the appropriate option.

**Keypad Tone**

*Menu 5-4*

This option allows you to select the tone that the keypad generates when you press a key. The following options are available.

**Tone:** each key, when pressed, makes a different sound.

**Beep:** each key, when pressed, makes the same sound.

**OFF:** the keys do not make any sound.

**Message Tone**

*Menu 5-5*

This option allows you to select how the phone informs you that a new message has been received. The following options are available.

**Single Tone:** the phone beeps once.

72

**Sound Settings**

**Periodic:** the phone beeps at regular intervals.

**Light Only:** the service light on the top of the phone flashes.

**Error Tone**

*Menu 5-6*

This option allows you to select how the phone informs you that you have made a mistake. The following options are available.

**ON:** the phone beeps to indicate an invalid entry.

**OFF:** the phone does not beep.

**Minute Minder**

*Menu 5-7*

This option allows you to specify whether the phone must beep every minute during an outgoing call to keep you informed of the length of your call. The following options are available.

**ON:** the phone beeps every minute.

**OFF:** the phone does not beep.

**Connect Tone**

*Menu 5-8*

This option allows you to specify whether the phone must beep when the phone connects to the network. The following options are available.

**ON:** the phone beeps when your call is accepted.

**OFF:** the phone does not beep.

73